

# **Perfect Shutters, inc.**

12213 Highway 173 - Hebron, IL 60034  
1-800-548-3336

## **Painting Instructions (FOR WOOD AND COMPOSITE ONLY)**

**DO NOT ALLOW SHUTTERS TO STAY IN THE SUN AND GET HOT PRIOR TO PAINTING OR AFTER PAINTING.**

- **RAW WOOD AND COMPOSITE.**
  - Lightly sand with a fine grit sand paper or sanding sponge.
  - Dust off all loose dust.
  - Spray or brush a coat of wood primer. ( Oil or Water base, Latex, is okay)
  - Let dry per instructions of primer manufacturer.
  - Sand until smooth.
  - Clean off dust.
  - Spray or brush a coat of paint (Oil or Water base, Latex, is okay).
  - Let dry per instructions of paint manufacturer.
  - Sand until smooth.
  - Clean off dust.
  - Spray or brush a second coat of paint.
  - Allow paint to cure per paint manufacturer's instructions prior to installing.

**DO NOT LEAN SHUTTERS AGAINST ONE ANOTHER EVEN IF THE PAINT FEELS DRY. THEY CAN STICK TOGETHER!**

- **PRIMED WOOD AND COMPOSITE.**
  - Sand until smooth.
  - Clean off dust.
  - Spray or brush a coat of paint (Oil or Water base, Latex, is okay).
  - Let dry per instructions of paint manufacturer.
  - Sand until smooth.
  - Clean off dust.
  - Spray or brush a second coat of paint.
  - Allow paint to cure per paint manufacturer's instructions prior to installing.

**DO NOT LEAN SHUTTERS AGAINST ONE ANOTHER EVEN IF THE PAINT FEELS DRY. THEY CAN STICK TOGETHER!**

**Should you have any further questions or comments, please call us at 800-548-3336, Monday through Friday, 7:30 am to 3:30 pm.**